




UK, IRL Heating / cooling relay Installation Manual
DE Heiz-/Kühl-Schaltmodul Montageanleitung
FR Relais H/C Notice d'installation
NL V/K schakelmodule Installatiehandleiding
IT Relè caldo/freddo Manuale di Installazione
ES Relé de calefacción / enfriamiento Manual de Instalación
PT Relé de aquecimento Manual de Instalação
SE Relä värme/kyla Installationsmanual
NO Rele for varme/kjøling Installationsmanual
DK Varmer / Kølerelæ Installationsmanual
FI Lämmitys-/ jäähdytysrele Asennusohjeet

1



2





Viitteen 1000517: 230 VAC, 50 Hz.
Viitteen 1000516: 24 VAC, 50 Hz.
Kulutus: 5VA.
Kontaktin ulostulo: 5A-250V, Min 10mA-12VDC.