

Instructions for Installation

Uponor FastGuard can be used as temporary or permanent protection, when there is a need for:

- Protection against poor ground conditions under the cable
- Protection for cables where the full installation depth cannot be obtained
- Protection of cables from impacts from machines on the construction site
- Temporary protection when other work is carried out in the vicinity of an active cable

The use of Uponor FastGuard is especially suitable for difficult conditions where strength requirements are high, for example, when the required fill height of SRN class cannot be achieved. The SRS cable protector can be used for a fill height of ≥ 0.25 m. Always follow local installation instructions.

Technical specifications:

Size: 110, 160


Length: 1M

Material: PP

Color: Yellow, Green, Red

Classification:


SRS according to EBR KJ41:21 Kabelförläggning max. 145 kV, SS 424 14 37 utg 6, and SPF verksnorm 5200



1. Place the pipe half without locks on the ground.



2. Insert the cable.




3. Place the pipe half with locks on top of the pipe half without locks.




4. Lock by hand or foot until you hear a click.





Disassembling the cable protector. Open the lock with your foot or hand. Lift the pipe half with locks straight upwards.



Uponor FastGuard is easy to assemble into long lengths. Uponor FastGuard stay connected, so that the installation can be done at the side of the cable trench and later lifted into place by hand or by machine. First, roll out the cable along the entire length next to the cable trench, install Uponor Split Cable Protectors and lift into place.